


XL PLEATED + CELLULAR SHADES MEASURE INSTRUCTIONS

ORDER IN 4 EASY STEPS

1. Select Mount Type:


Inside:

- Mounted within the window frame
- Provides a clean, built-in look
- Great way to leave attractive woodwork exposed
- If window frame isn't deep enough, please select outside mount



Outside:

- Great option when there is not enough depth for an inside mount
- Mounted to the wall, ceiling or molding surface surrounding the window
- Often used to make the window appear larger or to hide a less attractive window or door
- No minimum depth requirement




2. Measure:

Inside:

STEP 1: Measure the inside width at 3 locations – the top, middle and bottom. Record the smallest of the 3 measurements. This is your ordering width. We will make the necessary deductions (approx. $\frac{1}{4}'' - \frac{3}{8}''$)


STEP 2: Measure the height at 3 locations – the left side, middle and right side. Record the largest of the 3 measurements. This is your ordering length.



Outside:

STEP 1: Measure the width of the area you wish to cover. If space allows we recommend adding 2–3" (1–1½" each side) to this measurement to help eliminate light seepage. This is your ordering width and will be the overall measurement of the shade.

STEP 2: Measure the height of the area you wish to cover. This is your ordering length.



3. Select Control Type:

Standard Cord Lock:

- Allows you to raise and lower shade and lock in place
- As shade is raised, cord length increases
- Cleat included to wrap cord around for clean look and child safety
- No charge

Continuous Loop Control:

- Continuous cord allows for easy operation
- The cord always remains the same length no matter what position the shade is in
- Makes operating larger shades easier
- Surcharge applies

Cordless:

- Eliminate exposed cords
- Easy to adjust by lifting or lowering the shade with a gentle push or pull on the bottom rail
- Eliminates danger of dangling cords to children and pets
- Surcharge applies

4. Select Control Position: Left or Right

- This is the side of the shade that your control will hang from (left or right)
- Consider any obstacles that may interfere with operation (door handle, window opener, furniture location, etc.)


Mounting Requirements:

Product	Minimum Depth to Install	Minimum Depth for Flush Mount	Minimum Space for Outside Mount
with cord lock	$\frac{5}{8}''$	$2\frac{3}{8}''$	$\frac{5}{8}''$
with continuous loop	$\frac{7}{8}''$	$2\frac{1}{4}''$	$1\frac{3}{4}''$
with top down bottom up	$\frac{5}{8}''$	$2\frac{3}{8}''$	$\frac{5}{8}''$
with cordless system	$\frac{7}{8}''$	$2\frac{1}{4}''$	$1\frac{3}{4}''$

+ Optional Features:

Top Down / Bottom Up:

- Dual operation allows you to control privacy while still allowing light in
- Shade can be lowered from the top down and raised from the bottom up
- Not available with continuous loop control
- Surcharge applies



2 Shades on 1 Headrail:

- 2 shades hang from the same headrail and operate independently
- Total width you provide will be divided equally making both shades equal size (contact us for special requests)
- Small gap (approximately $\frac{1}{2}''$) will exist between the 2 shades
- Surcharge applies
- Controls will be positioned on the outside of each shade
- Available with standard cord lock only
- Not available for XL Pleated Shades

